


SPARES FOR PENDANT PUSH BUTTONS

				
CONTACT ELEMENT GREEN 1NC (SLPS1)	MULTI-SPEED CONTACT 1NO+1NO (SLPS2)	CONTACT ELEMENT GREEN 1NO (SLPS3)	CONTACT ELEMENT RED 1NC (SLPS4)	DOUBLE STEP (SLPS5)
				
EMERGENCY STOP (SLPS6)	KEY SWITCH E.S. (SLPS7)	MUSHROOM E.S. (SLPS8)	START/ALARM (SLPS9)	PUSH BUTTONS SINGLE SPEED BLACK/WHITE (SLPS10)
				
PUSH BUTTONS MULTIPLE SPEED BLACK/WHITE (SLPS11)	SINGLE STEP UP/DOWN WITH ELEMENT (SLPS12)	START WITH ELEMENT - GREEN (SLPS13)	STOP WITH ELEMENT-RED (SLPS14)	GREEN PUSH BUTTON (SLPS15)
				
BLUE PUSH BUTTON (SLPS16)	KEY SWITCH (SLPS17)	SELECTOR SWITCH (SLPS18)	INDICATING LAMP (SLPS19)	LAMP HOLDER (SLPS20)
 				
TWO MOTION UP/DOWN JOYSTICK WITH 1 CONTACT (SLPS21) TWO MOTION UP/DOWN JOYSTICK WITH 2 CONTACT (SLPS22)				




**COUPLING PLATE
(SLPP1)**



**COUPLING PLATE
(SLPP2)**



**INTERLOCKING PLATE
(SLPP3)**



**COUPLING PLATE
(SLPP4)**



**INTERLOCK TOP/BOTTOM
(SLPP5)**



**INTERLOCK "H" TYPE
(SLPP6)**



**HOUSING KIT FOR SV/2
(SLPVK1)**



**HOUSING KIT FOR SV/3
(SLPVK2)**



**HOUSING KIT FOR SV/5
(SLPVK3)**



**HOUSING KIT FOR SV/8
(SLPVK4)**



**HOUSING KIT FOR SV/10
(SLPVK5)**



**HOUSING KIT FOR SV/12
(SLPVK6)**



**HOUSING KIT
FOR SH/6
(SLPHK1)**



**HOUSING KIT
FOR SH/8
(SLPHK2)**



**HOUSING KIT
FOR SH/10
(SLPHK3)**



**HOUSING KIT
FOR SH/14
(SLPHK4)**



**CABLE SLEEVE
PB RANGE (2-3)
(SLPC1)**



**CABLE SLEEVE
PB RANGE (4-5)
(SLPC2)**



**CABLE SLEEVE PB
RANGE (6 & ABOVE)
(SLPC3)**




**CABLE CLAMP HOLDER
(SLPC4)**




**CABLE HOLDER
(SLPC5)**




**3 V BUTTONS PLATE
(SLPVP1)**




**5 V BUTTONS PLATE
(SLPVP2)**



**8 V BUTTONS PLATE
(SLPVP3)**



**12 V BUTTONS PLATE
(SLPVP4)**



**6 H BUTTONS PLATE
(SLPHP1)**



**8 H BUTTONS PLATE
(SLPHP2)**



**10 H BUTTONS PLATE
(SLPHP3)**



**12 H BUTTONS PLATE
(SLPHP4)**



**14 H BUTTONS PLATE
(SLPHP5)**